

INSTALLATION GUIDE

SUBSTRATE PREPARATION

- The substrate should be stable, dry and clean from all dirt, greasy stains and dust
- Panels should be installed after completion any wet renovation works in a room with a secured floor
- Appropriate air humidity: 45% -65%
- Correct room temperature: 18-22 degrees Celsius
- If installing over old paint finishes, the surface should be primed to negate the risk of falling the panels
- Before installation, it is necessary to acclimatize the panels in the conditions of the room

Recommended installation with the use of hybrid adhesive.



1. Open the package with the panels 48 hours before installation to allow the wood to adapt to the climate conditions.



2. Apply the glue evenly to the entire surface of the panel to make the panel stick firmly to the wall and stabilize the deformation of the wood.



3. Apply the panel to the target place, and then press it over the entire surface so that the glue is evenly connected to the substrate.



4. After application, wipe the dust off the panels with a dry microfiber cloth. You can also polish the panels with special wood preservatives.